

INSTALL SCREWS WHILE CONCRETE IS GREEN OR USE CONCRETE SCREWS IN DRILLED HOLES.

- DETAIL FOR FORMWORK ONLY
- ALL DETAILS, REINFORCING STEEL & CONCRETE MUST BE DESIGNED & CONFIRMED BY PROJECT STRUCTURAL ENGINEER AND / OR PROJECT ARCHITECT.



Nuform Building Technologies Inc.

100 Galcat Drive, Unit #2, Woodbridge, Ontario, Canada L4L 089 Tel: 905-652-0001 Fax: 905-652-0002 Toll Free: 1-877-747-9255 Web Page:www.nuformdirect.com CONFORM WALL GYPSUM WALL BOARD



