



NOTES:

- 1- PROVIDE WIRE HOOPS AT 3000mm[10'-0"] O/C MAX.
- 2- MINIMUM 2 HOOPS PER VERTICAL BAR
- 3- HOOPS ARE TACK WELDED OR TIE WIRED TO VERTICAL BARS AS REQUIRED
- 4- PLACE ALL VERTICAL BARS IN BOX CONNECTORS WHERE POSSIBLE

- DETAIL FOR FORMWORK ONLY
- ALL DETAILS, REINFORCING STEEL & CONCRETE MUST BE DESIGNED & CONFIRMED BY PROJECT STRUCTURAL ENGINEER AND / OR PROJECT ARCHITECT.



Nuform Building Technologies Inc.
100 Galcat Drive, Unit #2,
Woodbridge, Ontario, Canada L4L 0B9
Tel: 905-652-0001 Fax: 905-652-0002
Toll Free: 1-877-747-9255
Web Page: www.nuformdirect.com

**200mm[8"] CF8 WALL -
VERTICAL REINFORCING BARS**



DRAWING NO.		T043	
		COPYRIGHT 2024	
SCALE:		REVISION No.:	R00