



NOTES:

- 1- PROVIDE WIRE HOOPS AT 3000mm [10'-0"] O/C MAX.
- 2- MINIMUM 2 HOOPS PER VERTICAL BAR
- 3- HOOPS ARE TACK WELDED OR TIE WIRED TO VERTICAL BARS AS REQUIRED
- 4- PLACE ALL VERTICAL BARS IN BOX CONNECTORS WHERE POSSIBLE

- DETAIL FOR FORMWORK ONLY  
- ALL DETAILS, REINFORCING STEEL & CONCRETE MUST BE DESIGNED & CONFIRMED BY PROJECT STRUCTURAL ENGINEER AND / OR PROJECT ARCHITECT.



Nuform Building Technologies Inc.  
100 Galcat Drive, Unit #2,  
Woodbridge, Ontario, Canada L4L 0B9  
Tel: 905-652-0001 Fax: 905-652-0002  
Toll Free: 1-877-747-9255  
Web Page: www.nuformdirect.com

200mm [8"] CF8i WALL -  
VERTICAL REINFORCING BARS



DRAWING NO.		T045	
		COPYRIGHT 2024	
SCALE:		REVISION No.:	R00