



PLACEMENT HOOP  
#12 WIRE x 132φ



REINFORCED AT  
CENTERLINE OF  
CONCRETE



NOTES:

- 1- PROVIDE WIRE HOOPS AT 3000 O/C MAX.
- 2- MINIMUM 2 HOOPS PER VERTICAL BAR
- 3- HOOPS ARE TACK WELDED OR TIE WIRED TO VERTICAL BARS AS REQUIRED
- 4- PLACE ALL VERTICAL BARS IN BOX CONNECTORS WHERE POSSIBLE

- DETAIL FOR FORMWORK ONLY

- ALL DETAILS, REINFORCING STEEL & CONCRETE MUST BE DESIGNED & CONFIRMED BY PROJECT STRUCTURAL ENGINEER AND / OR PROJECT ARCHITECT.



Nuform Building Technologies Inc.

1 Regalcrest Court,  
Woodbridge, Ontario, Canada L4L 8P3  
Tel: 905-652-0001 Fax: 905-652-0002  
Toll Free: 1-877-747-9255  
Web Page: www.nuformdirect.com

100mm CF4 WALL -  
VERTICAL REINFORCING BARS



DRAWING NO.

T041

COPYRIGHT 2008

SCALE:

1:7.5

REVISION No.:

R00