




OPENING
N.T.S.



3
APPLY 6 mm CORNER BEAD  6 OF SEALANT AT TOP OF STARTER TO UNDERSIDE OF HEADER, AFTER WALL IS POURED.


DO NOT APPLY SEALANT IN INTERLOCKING JOINT.

2
INSTALL EXTERIOR LEG OF STARTER HOOKED INTO PANEL GROOVE, AND INTERIOR LEG OF STARTER IS SNAPPED INTO PLACE USING RUBBER Mallet. (DO NOT SLIDE STARTER IN PLACE).

1
APPLY 10 mm FLAT BEAD  5 OF SEALANT FULL HEIGHT TO EACH SIDE OF STARTER.



CONCRETE WALL WITH CONFORM



JAMB SECTION

- DETAIL FOR FORMWORK ONLY

- ALL DETAILS, REINFORCING STEEL & CONCRETE MUST BE DESIGNED & CONFIRMED BY PROJECT STRUCTURAL ENGINEER AND / OR PROJECT ARCHITECT.



Nuform Building Technologies Inc.
1 Regalcrest Court,
Woodbridge, Ontario, Canada L4L 8P3
Tel: 905-652-0001 Fax: 905-652-0002
Toll Free: 1-877-747-9255
Web Page: www.nuformdirect.com

CONFORM WALL OPENING CONFORM STARTER AT DOOR JAMB



DRAWING NO.

A090

COPYRIGHT 2008

SCALE:

1:2.5

REVISION No.:

R00