


CAULKING AND BACKING ROD  
REMOVE INSULATION AS REQUIRED  
AFTER CONCRETE IS SET

RIGID INSULATION  
FULL WIDTH & FULL  
HEIGHT OF WALL

200mm CF8i WALL

UNCORED STARTER  
EACH SIDE

EXPANSION JOINT AS  
REQUIRED (25 MIN.)



- DETAIL FOR FORMWORK ONLY

- ALL DETAILS, REINFORCING STEEL & CONCRETE MUST  
BE DESIGNED & CONFIRMED BY PROJECT STRUCTURAL  
ENGINEER AND / OR PROJECT ARCHITECT.



Nuform Building Technologies Inc.

1 Regalcrest Court,  
Woodbridge, Ontario, Canada L4L 8P3  
Tel: 905-652-0001 Fax: 905-652-0002  
Toll Free: 1-877-747-9255  
Web Page: www.nuformdirect.com

## 200mm CF8i WALL - EXPANSION JOINT



DRAWING NO.

**T821**

COPYRIGHT 2008

SCALE:

**1:7.5**

REVISION No.:

**R00**