

## HEADER SECTION

200mm CF8 WALL

NO SEALANT ABOVE FLASHING

FLASHING INSTALLED AS DETAIL A092

25 200 40

17  
APPLY SEALANT WITH BACKING ROD ALL AROUND AT EACH SIDE OF WINDOW FRAME

WINDOW (BY OTHERS)

## OPENING

14

APPLY 6mm CORNER BEAD OF SEALANT AT TOP AND BOTTOM OF STARTER TO FLASHING AT HEADER AND SILL OF OPENING.

## JAMB SECTION

UNCORED CONFORM STARTER INSTALLED AS DETAIL A091

15

ANCHOR WINDOW AS REQUIRED BY WINDOW MANUFACTURER

## SILL SECTION

WINDOW (BY OTHERS)

17  
APPLY SEALANT WITH BACKING ROD ALL AROUND AT EACH SIDE OF WINDOW FRAME

FLASHING INSTALLED AS DETAIL A093

25  
TO SUIT WINDOW FRAME

WINDOW SILL AND CASING (BY OTHERS)

- DETAIL FOR FORMWORK ONLY

- ALL DETAILS, REINFORCING STEEL & CONCRETE MUST BE DESIGNED & CONFIRMED BY PROJECT STRUCTURAL ENGINEER AND / OR PROJECT ARCHITECT.



Nuform Building Technologies Inc.  
1 Regalcrest Court,  
Woodbridge, Ontario, Canada L4L 8P3  
Tel: 905-652-0001 Fax: 905-652-0002  
Toll Free: 1-877-747-9255  
Web Page: www.nuformdirect.com

200mm CF8 WALL -  
HOLLOW METAL WINDOW



DRAWING NO.

A223

COPYRIGHT 2008

SCALE:

1:5

REVISION No.:

R00